

1. Unfold fabric panels into podium shape. (Figure 1)
2. Place gussett into holes in fabric panels to hold in place. (Figure 2)
3. Flip cabinet over and repeat step 2 for the bottom.
4. Latch hook panels in the back together. (Detail 1)
5. Place counter top on the top of cabinet with grooves on the underneath side aligning with the splines. (Figure 3)
6. Place assembled cabinet in front of the Evolution system. Curve in the back of the counter top should be aligned with the curve of the system. (Figure 4)

